



Quick Connection Guide



Quick Connection Guide

Before you start to configure your Wi-Fi Air Conditioner, make sure your smart phone has connected to the router which can reach the internet and the AC is properly installed.

1: Scan below QR code, open with your smart phone browser to download Electrolux APP.

iOS:



Android:




Or search “**Electrolux Home Comfort**” in Apple store or Google play.




Electrolux Home Comfort


- 2: Open APP and click on “**REGISTER**”.
- 3: ① Type in Email address;
② Click “**SEND**”;
③ Type in Verification Code that you just received in your email box;
④ Type in your Password;
⑤ Click “**CREATE ACCOUNT**”.



4: Click **“Confirm”** when this page appears.




5: Click the **“+”** button on the top right corner.




6: Scan the QR code on the below.


If there is no QR code on the unit, click **“CONTINUE WITHOUT SCANNING”**, then choose your model manually.




- 7: Power on the AC, then press the “LED” button on the remote controller for 7 times in 10 seconds.
The Wi-Fi LED will start to blink.



- 8: ① Check the Wi-Fi name;
② Type in the password of the router;
③ Click “CONFIGURE”.





- 9: Name your AC and Click “NEXT”, then the configuration process is completed.



If you failed to configure your AC at the first time in step 9, you can choose “**Retry**” and repeat the process from Step 8. Or you can choose the “**Access Point**” solution:

1. Choose the “**Access point**” when Failed to connect to the network window pops up.
2. Input the password of the router, click “**NEXT**”.



3. Open the Wi-Fi settings on your phone and select the network “Air Conditioner”. Return to the Electrolux app, and click “**NEXT**”.
4. Name your AC and Click “**NEXT**”, then the configuration process is completed.

